

Assembly of Bowl and Pedestal -

1. When bowl and pedestal are sanded nearly ready-to-finish, glue bowl to pedestal using a ½" plug to center, then clamp assembly until dry.
2. Mount assembly to the Ring Master arbor using the pedestal threads to complete sanding or center bowl bottom, then touch up sanding, and application of finish if desired.

